# Distributed Software Systems Exercise 6

Python Folder Monitor Daemon for Linux

#### libraries

- signal: handles system interrupts and signals
- watchdog: used to monitor file system events
- daemon: enables the program to be created as a daemon process
- lockfile: manages concurrent access to files
- syslog: makes the program able to interact with syslogd system module

```
import sys
import time
import os
import signal
from datetime import datetime
from watchdog.observers import Observer
from watchdog.events import FileSystemEventHandler
import daemon
import daemon.pidfile
import lockfile
import syslog
```

#### listeners

```
class FileEventHandler(FileSystemEventHandler):
    Codeium: Refactor | Explain | Generate Docstring | ×
    def __init__(self):
         super().__init__()
         syslog.openlog("directory-monitor", syslog.LOG_PID)
    Codeium: Refactor | Explain | Generate Docstring | ×
    def on_created(self, event):
         if not event.is_directory:
             syslog.syslog(syslog.LOG_INFO, f"File_created: {os.path.basename(event.src_path)}")
    Codeium: Refactor | Explain | Generate Docstring | ×
    def on_modified(self, event):
         if not event.is_directory:
             sysloq.sysloq.LOG_INFO, f"File modified: {os.path.basename(event.src_path)}")
    Codeium: Refactor | Explain | Generate Docstring | ×
    def on deleted(self, event):
         if not event is directory:
             syslog.syslog(syslog.LOG_INFO, f"File deleted: {os.path.basename(event.src_path)}")
    Codeium: Refactor | Explain | Generate Docstring | ×
    def on_moved(self, event):
         if not event.is_directory:
             syslog.syslog(syslog.LOG_INFO, f"File renamed: {os.path.basename(event.src_path)} to {os.path.basename(event.dest_path)}")
```

#### listeners

- basically creates an event tied to every action happening in the folder (creation, modification, delete, move)
- prints to the syslogd module when one of these action are performed

## monitor-directory

- uses the observer library to choose a directory to monitor
- sets the previously created Event Handler as the event handler for the observer

```
def monitor_directory():
    if not os.path.exists(MONITOR_DIR):
        syslog.syslog(syslog.LOG_ERR, f"Monitor directory {MONITOR_DIR} does not exist!")
        sys.exit(1)

    event_handler = FileEventHandler()
    observer = Observer()
    observer.schedule(event_handler, MONITOR_DIR, recursive=False)

try:
    syslog.syslog(syslog.LOG_INFO, f"Starting directory monitor for: {MONITOR_DIR}")
    observer.start()

    while True:
        time.sleep(1)

except Exception as e:
    syslog.syslog(syslog.LOG_ERR, f"Error in monitor_directory: {str(e)}")
    observer.stop()
    raise
finally:
    observer.join()
```

### run\_daemon

- runs the program as a system daemon setting also its attributes:
  - umask= 00002: sets permission for accessing files and directories, rw-rw-r– for files and rwxrwxr-x for directories
  - pidfile= writes its process id to the file specified as value for PID FILE
  - detach\_process: detach from the terminal, run in the background
- run the daemon with directory\_monitor\_daemon.py start|stop|status

```
def run_daemon():
    context = daemon.DaemonContext(
        working_directory=MONITOR_DIR,
        umask=00002,
        pidfile=daemon.pidfile.PIDLockFile(PID_FILE),
        detach_process=True
    )
    with context:
        monitor_directory()
```

# **Testing**

- a test\_monitor.py file is provided in the repository
- run it after starting the daemon to test it
- crontab can be used to run the test twice per day.
- the test\_monitor.py is able to simulate operations for "different days", if you
  run it while the daemon is in execution you should see an output like this

```
ratchef@nobara-pc:~/Documenti/GitHub/dis_sys$ sudo grep 'directory-monitor' /var/log/messages | sort
[sudo] password di ratchef:
Nov 1 16:15:37 nobara-pc directory-monitor[30196]: Starting directory monitor daemon
Nov 1 16:16:07 nobara-pc directory-monitor[30466]: Starting directory monitor daemon
Nov 1 16:16:07 nobara-pc directory-monitor[30468]: Starting directory monitor for: /home/ratchef/.directory_monitor/monitored
Nov 1 16:16:24 nobara-pc directory-monitor[30468]: File created: test file day0 20241101 161624.txt
Nov 1 16:16:24 nobara-pc directory-monitor[30468]: File modified: test_file_day0_20241101_161624.txt
Nov 1 16:16:25 nobara-pc directory-monitor[30468]: File modified: test_file_day0_20241101_161624.txt
Nov 1 16:16:25 nobara-pc directory-monitor[30468]: File renamed: test_file_day0_20241101_161624.txt to renamed_day0_20241101_161624.txt
Nov 1 16:16:26 nobara-pc directory-monitor[30468]: File deleted: renamed_day0_20241101_161624.txt
Nov 1 16:16:26 nobara-pc directory-monitor-test[30686]: Completed test sequence for day 0
Nov 1 16:16:28 nobara-pc directory-monitor[30468]: File created: test_file_day1_20241102_161628.txt
Nov 1 16:16:28 nobara-pc directory-monitor[30468]: File modified: test file day1 20241102 161628.txt
Nov 1 16:16:29 nobara-pc directory-monitor[30468]: File modified: test file day1 20241102 161628.txt
Nov 1 16:16:29 nobara-pc directory-monitor[30468]: File renamed: test_file_day1_20241102_161628.txt to renamed_day1_20241102_161628.txt
Nov 1 16:16:30 nobara-pc directory-monitor[30468]: File deleted: renamed_day1_20241102_161628.txt
Nov 1 16:16:30 nobara-pc directory-monitor-test[30686]: Completed test sequence for day 1
```